

Maintenance Instructions for FlexBar



To ensure your Flexbar remains functional and retains its stylish design for many years, please follow these maintenance guidelines:

1

Regular Cleaning

Clean the bar with mild cleaning products and a soft cloth to avoid damaging the surface. Avoid using harsh chemicals or abrasive materials that could scratch or harm the finish. For stains on the bar top, we recommend spraying WD40 and gently wiping with a soft cloth.

2

Tighten Screws

Check and tighten all screws at least once a year, or more often if the bar is used frequently. This ensures the bar stays stable and safe to use.

3

Cleaning Accessories

Empty and clean ice buckets and other accessories after each use. Wipe down the interior of the bar regularly to keep it fresh and hygienic.

4

Protection & Transport

Always transport the bar in an upright position and ensure it is well protected to prevent damage. Use the original packaging when transporting the bar in any vehicle, such as cars, trucks, or vans. Wooden bars are for indoor use only and should always be stored in a dry place.

5

For Outdoor Use

FlexBar Black and FlexBar Stainless Steel are specially designed for outdoor use. However, we recommend storing the bar indoors when not in use to extend its lifespan and protect it from unnecessary wear caused by weather conditions.

6

Check Wheels and Mechanisms

Regularly inspect the condition of the wheels and lubricate them if necessary to ensure smooth movement. Check the hinges and folding mechanisms to ensure they function correctly. Lubricate with an appropriate product if needed.

7

Avoid Overloading

Always follow the recommended maximum weight of 50 kg (110 lbs) for the worktop. Overloading can damage the bar and reduce its lifespan.